Overnight Instructions for Dry Inflatables

Your inflatable/equipment is scheduled for an overnight rental. Whether you ordered your item for multiple days, or our delivery team is just not able to make it back to you, here are some helpful tips for a successful overnight rental!

After a fun day of play please follow these steps.

1. Double-check to make sure your sprinklers are turned off. Dry items do incur a minimum of a $250 fee per unit that is wet.
2. When shutting down the inflatable
    a. Make sure no one is in or around the inflatable.
    b. Walk to the back of the unit and switch the blower off.
    c. Make sure the inflatable deflates on itself and not onto foreign objects or structures.
3. For safety purposes we recommend that you unplug the inflatable, so the kids/guests do not turn it back on while you are unavailable to supervise the unit.

The next day's tips

- Pick up of the inflatable will happen after 7:00 a.m. or your scheduled time the next day.
- You are welcome to continue having fun the next day but unless you are scheduled for a later pickup, we do recommend that you use this time as extra free play and do not plan an event as we could pick up at any time.

Trouble Shooting

- If the inflatable turns off, check your circuit breaker or GFI to make sure you have power.
- Make sure the item is plugged in and did not accidentally become unplugged.
- Make sure there is nothing up against the blower that would restrict airflow.

Still have a problem or questions please TEXT the office at 480-854-1857